

ENJOYCARE

Folding Walking Stick

Model **EK-8031** · Joy Ours part no. **JOY-WALK-8031**


A light aluminium folding stick with five push-button heights from 83.8 to 94 cm and elastic-corded sections.

KEY FEATURES

- **Five push-button heights** Set the stick anywhere from 83.8 to 94 cm.
- **Elastic-corded sections** The sections stay joined, so it folds down quickly to carry or store.
- **Light aluminium shaft** Light to carry and rust resistant.
- **Rubber tip** Grips the ground with each step.
- **Wrist strap** Keeps the stick close when you need your hand for something else.

SPECIFICATIONS

Tip	Rubber
Shaft	Aluminium
Colour	Black
Height Range	83.8–94 cm
Handle Length	12.7 cm
Height Settings	5
Version	A, B

WHO IT SUITS

- People who use a stick some of the time and want it folded away the rest
- Outings and appointments where the stick needs to fit in a bag
- Users who suit a stick height between 83.8 and 94 cm
- People who want a plain, light single-tip stick

GOOD TO KNOW

- When you unfold it, make sure each section is fully seated and the push button has clicked through before you lean on the stick.
- Check the rubber tip regularly for wear.