

ENJOYCARE

Spring-Assisted Chopsticks

Model **EK-B905** · Joy Ours part no. **JOY-DALY-B905**



Spring-assisted chopsticks you squeeze to pick food up; the spring opens them again by itself.

KEY FEATURES

- **Squeeze to pick up** No chopstick technique needed: press the handles together to grip food.
- **Opens by itself** The spring opens the tips again each time you relax your fingers.
- **Finger rests** Shaped rests and a non-slip handle help your fingers stay in place.
- **Removable bamboo tips** Natural bamboo tips pull out for cleaning or replacement.
- **Spare tips included** A second pair of bamboo tips comes with the chopsticks.
- **Left or right hand** Works the same way in either hand.

SPECIFICATIONS

Colour	Green
Handle	13 × 5.5 cm
Length	approx. 22 cm
Weight	approx. 35.5 g
Material	Food-grade PP, natural bamboo
Tip Length (Exposed)	9 cm
Tip Fitting	Push-in, removable
Spare Tips	1 pair included
Handedness	Left or right hand

WHO IT SUITS

- People who like eating with chopsticks but find the usual grip hard
- Reduced hand dexterity that makes holding two separate sticks difficult
- Users who can pinch and don't need loops to keep their fingers in place
- Left- or right-handed users

GOOD TO KNOW

- Pull the bamboo tips out to wash them separately from the handle.
- Keep the spare pair of tips for when the first pair needs replacing.