ENJOYCARE

Finger-Loop Spring Chopsticks

Model **EK-B936** · Joy Ours part no. **JOY-DALY-B936**

Spring chopsticks with a finger loop on each side, so they stay in the hand while you squeeze to pick up food.

KEY FEATURES

- **Finger loops** A loop on each side keeps the chopsticks in the hand.
- **Spring opening** Opens by itself each time you relax your grip.
- **Squeeze to pick up** Pinch with thumb and fingers; no traditional chopstick grip needed.
- **Removable bamboo tips** Push-in tips pull out for cleaning or replacement, with a spare pair included.
- **Left or right hand** Works the same way in either hand.

SPECIFICATIONS

Tips	Bamboo, removable
Handle	13.5 × 5.5 cm
Length	22.5 cm
Weight	approx. 43 g
Tip Length (Exposed)	9 cm
Finger Loops	2, one on each side
Spare Tips	1 pair included
Handedness	Left or right hand

WHO IT SUITS

- People whose fingers slip off ordinary or spring chopsticks
- A weak grip that makes it hard to keep chopsticks in position
- Anyone who wants to keep eating with chopsticks without the traditional technique
- Left- or right-handed users

GOOD TO KNOW

- Remove the bamboo tips to wash them, then push them back into the handle.
- Keep the spare tips for when a pair needs replacing.